

ROUTINE MAINTENANCE

ROUTINE SERVICING CHART

OPERATION	FREQUENCY (Whichever occurs First)	SPEEDOMETER READING (Miles & Kilometers)			SECTION
		1000 MILES (1600 Kms) A SERVICE	6000 MILES (10000 Kms) B SERVICE	12000 MILES (20000 Kms) C SERVICE	
AIR FILTER ELEMENTS CLEAN	MONTHLY IN DUSTY CON- DITIONS		✓	✓	E5
BATTERY TERMINALS AND ELECTROLYTE LEVELS		✓	✓	✓	H1
BRAKE FLUID LEVEL	MONTHLY	✓	✓	✓	F1
BRAKE FLUID CHANGE	ANNUALLY				F4
BRAKE & CLUTCH LEVERS LUBRICATE	MONTHLY	✓	✓	✓	A14
BRAKE PAD WEAR EXAMINE	MONTHLY or every 3000 miles		✓	✓	F2
BRAKE PEDAL PIVOT GREASE	3 MONTHS	✓	✓	✓	A15
BRAKE CALIPER (rear) MOUNTING PLATE LUBRICATE	3 MONTHS	✓	✓	✓	A13
CARBURETTOR DAMPER PISTON OIL LEVEL EXAMINE	MONTHLY		✓	✓	B7
CARBURETTOR SUCTION CHAMBERS & DAMPER PISTONS CLEAN	AS REQUIRED		✓	✓	B5
CARBURATION EXAMINE	AS REQUIRED	✓			B7
CLUTCH CABLE EXAMINE		✓	✓	✓	G4
FRONT FORK OIL CHANGE				✓	A12
GEARBOX OIL LEVEL EXAMINE (Single Rotor Idling Models)	3 MONTHS	✓			A7
GEARBOX OIL CHANGE			✓	✓	A7
MICROSWITCH ADJUSTMENT EXAMINE			✓	✓	B11
PRIMARY DRIVE OIL LEVEL EXAMINE	3 MONTHS	✓			A8
PRIMARY DRIVE OIL CHANGE			✓	✓	A8
OIL METERING UNIT ADJUSTMENT EXAMINE		✓	✓	✓	A6
REAR DRIVE CHAIN ADJUSTMENT EXAMINE	AS REQUIRED	✓			D10
REAR DRIVE CHAIN OIL CHANGE			✓	✓	A9
STEERING HEAD BEARING ADJUSTMENT EXAMINE		✓	✓	✓	G13
SPARK PLUGS EXAMINE & CLEAN			✓	✓	H4
SPARK PLUGS CHANGE	AS REQUIRED				H4
THROTTLE CABLE EXAMINE		✓	✓	✓	G3
WHEEL ALIGNMENT		✓	✓	✓	F19

DAILY ROUTINE CHECKS

TYRES, LIGHTS, ENGINE OIL LEVEL, BRAKE OPERATION, HORN, REAR VIEW MIRROR ADJUSTMENT

ROUTINE MAINTENANCE

Refer to Sections A1 & A2 for Lubrication Chart and Recommended Lubricants

FIRST 1000 MILE SERVICE (1600 km)		<i>Section</i>
Examine and adjust	Oil metering pump unit	A6
	Steering head bearings	G13
	Throttle cable	G3
	Clutch cable	G4
	Rear chain	D10
	Wheel alignment	F19
Examine and adjust oil levels	Oil tank	A1
	Carburettor damper piston	B7
	Primary chaincase	A8
	Gearbox	A7
	Rear chaincase	A9
	Brake master cylinder reservoirs	F1
Lubricate	Brake & clutch lever pivots (handlebar)	A14
	Rear brake pedal pivot	A15
Grease	Rear brake caliper mounting plate pivot	A13
Check	Battery terminal and electrolyte level	H1
	Lights	H11 to H18
	Tyres	F15
	Wheel alignment	F19
	Security of: All fairing brackets and mounting points	
	Screen mounting screws	
EVERY 6000 (10,000 km) AND 12,000 MILES (20,000 km)		
Examine and replace where necessary	Brake pads	F2
Drain and refill to correct level	Primary chaincase	A8
	Gearbox	A7
	Rear chaincase	A9
Check and Re-adjust where necessary	Oil metering pump unit	A6
	Steering head bearings	G13
	Micro-switch	B11
	Throttle cable	G3
	Clutch cable	G4
	Rear drive chain	D10
	Wheel alignment	F19
Remove, clean and re-fit	Spark plug	H4
	Air filter element	E5
	Carburettor suction chambers	B5
Lubricate with oil	Carburettor damper piston	B7
	Rear brake pedal	A15
Lubricate with grease	Rear brake caliper mounting plate pivot	A13
Check	Battery terminals & electrolyte level	H1
	Lights	H11 to H18
	Tyres	F15
ADDITIONAL AT 12000 MILES (20,000 km)		
Drain and refill to correct level	Front forks	A12
Monthly	Check brake pads	F2
	Oil level – carburettor damper piston	B7
Annually	Drain and refill brake hydraulic system	F4